

**FURUNO**

# **NAV***pilot*

AUTO PILOT

**NAVpilot-700**

**NAVpilot-711**

**NAVpilot-720**



**NAVpilot-700**



**NAVpilot-711**



**NAVpilot-720**



**FURUNO ELECTRIC CO., LTD.**

[www.furuno.co.jp](http://www.furuno.co.jp)

**ECF**

(Elemental Chlorine Free)

The paper used in this manual  
is elemental chlorine free.

**FURUNO ELECTRIC CO., LTD.**

9-52 Ashihara-cho,  
Nishinomiya, 662-8580, JAPAN

Telephone : +81-(0)798-65-2111

Fax : +81-(0)798-65-4200

• FURUNO Authorized Distributor/Dealer

All rights reserved. Printed in Japan

A : DEC. 2009

Pub. No. OME-72720-A

(DAMI ) NAVpilot-700/711/720



\* 0 0 0 1 7 1 8 1 2 1 0 \*

# IMPORTANT NOTICES

---

## General

- This manual has been authored with simplified grammar, to meet the needs of international users.
- The operator of this equipment must read and follow the descriptions in this manual. Wrong operation or maintenance can cancel the warranty or cause injury.
- Do not copy any part of this manual without written permission from FURUNO.
- If this manual is lost or worn, contact your dealer about replacement.
- The contents of this manual and equipment specifications can change without notice.
- The example screens (or illustrations) shown in this manual can be different from the screens you see on your display. The screens you see depend on your system configuration and equipment settings.
- Save this manual for future reference.
- Any modification of the equipment (including software) by persons not authorized by FURUNO will cancel the warranty.
- All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

## How to discard this product


Discard this product according to local regulations for the disposal of industrial waste. For disposal in the USA, see the homepage of the Electronics Industries Alliance (<http://www.eiae.org/>) for the correct method of disposal.

## How to discard a used battery

Some FURUNO products have a battery(ies). To see if your product has a battery(ies), see the chapter on Maintenance. Follow the instructions below if a battery(ies) is used.


### In the European Union

The crossed-out trash can symbol indicates that all types of batteries must not be discarded in standard trash, or at a trash site. Take the used batteries to a battery collection site according to your national legislation and the Batteries Directive 2006/66/EU.



### In the USA

The Mobius loop symbol (three chasing arrows) indicates that Ni-Cd and lead-acid rechargeable batteries must be recycled. Take the used batteries to a battery collection site according to local laws.





### In the other countries

There are no international standards for the battery recycle symbol. The number of symbols can increase when the other countries make their own recycle symbols in the future.













# SAFETY INSTRUCTIONS




Please read these safety instructions before you operate the equipment.

 <b>WARNING</b>	Indicates a condition that can cause death or serious injury if not avoided.
 <b>CAUTION</b>	Indicates a condition that can cause minor or moderate injury if not avoided.





 Warning, Caution	 Prohibitive Action	 Mandatory Action
--	--	--

 <b>WARNING</b>	
	<b>Do not open the equipment unless you are well familiar with electrical circuits.</b>  Only qualified personnel should work inside the equipment.
	<b>Do not set the course changing speed too high.</b>  The boat will be turned too sharply at the course change, which could create a very dangerous situation.
	<b>Do not use the autopilot in the following situations:</b>  - Harbor entrance or narrow channel - Where vessels change course often, such as a cape or small island
	<b>Observe the following cautions when using the autopilot:</b>  - Maintain a vigilant watch - Watch for drifting of vessel
	<b>In an emergency, manually steer the vessel.</b>  The autopilot cannot avoid vessels, etc. automatically.
	<b>Do not use the SIMULATION mode on the boat.</b>  The rudder may move suddenly. This is a special-purpose mode for technicians.

 <b>WARNING</b>	
	<b>Do not use the ORBIT mode in rough seas.</b>  Because the boat turns a 360° circle around the waypoint, a large wave or strong wind can cause the boat to capsize.
	<b>For the figure-eight mode, confirm that no object is in the general vicinity of the waypoint.</b>  The distance from the waypoint to the turning point depends on boat's speed.

 <b>CAUTION</b>	
	<b>In case of power failure, turn off the autopilot or manually steer the vessel.</b>  Leaving the equipment in the AUTO or NAV mode during power failure will cause wear on the rudder mechanism.
	<b>Use the correct fuse.</b>  Use of a wrong fuse can cause fire or damage the equipment.

**WARNING LABEL**  
 A warning label is attached to the processor unit. Do not remove the label. If the label is missing or damaged, contact your dealer about replacement.

 <b>WARNING</b> 
To avoid electrical shock, do not remove cover. No user-serviceable parts inside.
 

Name: Warning Label (1)  
 Type: 86-003-1011  
 Code No.: 100-236-231

# TABLE OF CONTENTS

---

<b>FOREWORD</b> .....	<b>vi</b>
<b>SYSTEM CONFIGURATION</b> .....	<b>vii</b>
<b>1. INTRODUCTION</b> .....	<b>1-1</b>
1.1 Controls.....	1-1
1.1.1 Control Unit FAP-7001 .....	1-1
1.1.2 Control Unit FAP-7011 .....	1-2
1.1.3 Control Unit FAP-7021 .....	1-2
1.2 How to Turn Power On, Off.....	1-3
1.3 How to Adjust Brilliance, Contrast .....	1-4
1.3.1 NAVpilot-700 .....	1-4
1.3.2 NAVpilot-711, NAVpilot-720 .....	1-4
1.4 Displays in the STBY and AUTO Modes .....	1-5
1.4.1 Content of displays in the STBY and AUTO modes.....	1-5
1.4.2 Graphic displays.....	1-8
1.4.3 How to select the data to display in the STBY mode .....	1-11
<b>2. STEERING MODES</b> .....	<b>2-1</b>
2.1 STBY Mode .....	2-1
2.2 AUTO Modes.....	2-2
2.2.1 AUTO mode .....	2-2
2.2.2 ADVANCED AUTO mode .....	2-4
2.3 NAV Mode .....	2-6
2.3.1 How to get the NAV mode.....	2-6
2.3.2 Sailing method for the NAV mode .....	2-8
2.3.3 Waypoint switching method.....	2-9
2.3.4 How to set the steering behavior of your boat after you arrive to a waypoint.....	2-9
2.4 TURN Mode.....	2-10
2.4.1 How to select a turn and start the turn .....	2-10
2.4.2 180° turn.....	2-11
2.4.3 360° turn.....	2-11
2.4.4 User turn.....	2-11
2.5 FishHunter Mode .....	2-12
2.5.1 How to preset FishHunter turn parameters .....	2-12
2.5.2 How to select a FishHunter turn and start the turn .....	2-13
2.5.3 Circle turn .....	2-14
2.5.4 Orbit turn .....	2-15
2.5.5 Spiral turn .....	2-15
2.5.6 Figure-eight turn .....	2-16
2.5.7 Square turn.....	2-16
2.5.8 Zigzag turn .....	2-16
2.6 How to Navigate to a TLL Position .....	2-17
2.7 REMOTE Mode .....	2-17
2.7.1 Dial-type remote controller (FAP-5551, FAP-5552) .....	2-17
2.7.2 Button-type remote controller (FAP-6211, FAP-6212), Dodge-type remote controller (FAP-6231, FAP-6232), Lever-type remote controller (FAP-6221, FAP-6222).....	2-18
2.8 DODGE Mode .....	2-21
2.8.1 How to dodge in the STBY mode .....	2-21
2.8.2 How to dodge in the AUTO and NAV modes .....	2-21
2.9 WIND Mode (for sailboats).....	2-22
2.9.1 How to get the WIND mode.....	2-22

## TABLE OF CONTENTS

2.9.2	Wind angle mode .....	2-23
2.9.3	TACK mode.....	2-24
2.9.4	Tacking in WIND mode (WIND TACK).....	2-25
<b>3.</b>	<b>ALARMS .....</b>	<b>3-1</b>
3.1	ALARM Menu.....	3-1
3.2	Alarm Buzzer.....	3-2
3.3	Buzzer Interval .....	3-2
3.4	Watch Alarm.....	3-3
3.5	Deviation Alarm.....	3-3
3.6	XTE Alarm.....	3-4
3.7	Arrival Alarm.....	3-5
3.8	Speed Alarm .....	3-5
3.9	Depth Alarm .....	3-6
3.10	Water Temperature Alarm.....	3-6
3.11	Trip Distance Alarm, Trip Distance Reset .....	3-7
3.11.1	How to set the log trip alarm .....	3-7
3.11.2	How to reset the trip distance.....	3-7
3.12	Wind Alarms (for sailboats).....	3-8
3.12.1	Heading change alarm.....	3-8
3.12.2	Wind shift alarm .....	3-9
3.12.3	True wind speed alarm.....	3-9
3.12.4	Apparent wind speed alarm .....	3-9
3.13	Alarm Log.....	3-10
<b>4.</b>	<b>HOW TO CUSTOMIZE YOUR NAVPILOT .....</b>	<b>4-1</b>
4.1	Parameter Setup (PARAMETER SETUP Menu) .....	4-1
4.1.1	Sea state .....	4-2
4.1.2	Trim gain .....	4-5
4.1.3	Speed calculation.....	4-6
4.2	Net Towing .....	4-6
4.3	Course After Operation of a Remote Controller .....	4-7
4.4	Nav Data Source.....	4-7
4.5	NAVnet vx2 Synchronization.....	4-8
4.6	SYSTEM SETUP Menu .....	4-9
4.7	Menu Shortcuts .....	4-12
4.7.1	How to create a menu shortcut .....	4-12
4.7.2	How to delete a menu shortcut .....	4-13
<b>5.</b>	<b>MAINTENANCE, TROUBLESHOOTING.....</b>	<b>5-1</b>
5.1	Preventive Maintenance.....	5-1
5.2	Replacement of Fuse .....	5-2
5.3	Diagnostics.....	5-2
5.3.1	Diagnostic menu .....	5-2
5.3.2	Processor unit test .....	5-3
5.3.3	Control unit test.....	5-3
5.3.4	NMEA0183 test.....	5-4
5.3.5	CAN bus test.....	5-4
5.3.6	Keyboard test.....	5-5
5.3.7	Screen test.....	5-5
5.3.8	Rudder test.....	5-6
5.3.9	Compass (heading sensor) test .....	5-7
5.4	System Data.....	5-8

- 5.5 Messages .....5-9
  - 5.5.1 Message pop-up display .....5-9
  - 5.5.2 Message board.....5-9
  - 5.5.3 Message description .....5-9
  
- APPENDIX 1 MENU TREE .....AP-1**
- SPECIFICATIONS ..... SP-1**
- INDEX ..... IN-1**

# FOREWORD

---

## **A Word to the Owner of the NAVpilot-700/711/720**

Congratulations on your choice of the NAVpilot-700/711/720. We are confident you will see why the FURUNO name has become synonymous with quality and reliability.

For over 60 years FURUNO Electric Company has enjoyed an enviable reputation for innovative and dependable marine electronics equipment. This dedication to excellence is furthered by our extensive global network of agents and dealers.

Your equipment is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless properly operated and maintained. Please carefully read and follow the operation and maintenance procedures set forth in this manual.


Thank you for considering and purchasing FURUNO.

We would appreciate feedback from you, the end-user, about whether we are achieving our purposes.

## **Features**

- “Adaptive” technology allows NAVpilot to continue improving your vessel’s steering on every voyage
- Versatile, high-resolution monochrome LCDs provide a variety of user-defined display configurations
- Auto set-up and self-learning for vessel speed and course
- One-touch operation for STBY, NAV and AUTO modes
- “FishHunter” guides your vessel in circle, orbit, spiral, figure-eight, square or zigzag maneuver around fish or other target
- The NAVpilot-720 (handheld type) can work as a full-functioned remote control unit within a NAVpilot system
- Network up to six full-size NAVpilot-700, compact NAVpilot-711 and/or handheld NAVpilot-720 control units

# SYSTEM CONFIGURATION



\*: ANY COMBINATION OF FAP-7001 AND 7011 IS AVAILABLE. ALSO, FAP-7021 CAN BE CONNECTED AT THE END OF SERIES.

This page is intentionally left blank.

# 1. INTRODUCTION


---

## 1.1 Controls

The Control Unit for your NAVpilot is either the FAP-7001, FAP-7011, or FAP-7021.


The descriptions in this manual mainly follow the key names of the NAVpilot-700 (Control Unit FAP-7001). Refer to the table below for equivalent controls on the NAVpilot-711 and NAVpilot-720.

### 1.1.1 Control Unit FAP-7001




1. INTRODUCTION

1.1.2 Control Unit FAP-7011



1.1.3 Control Unit FAP-7021




## 1.2 How to Turn Power On, Off

Control unit	Key	ON	OFF
FAP-7001	POWER/BRILL	Short-press	Long-press*
FAP-7011	POWER/STBY	Short-press	Long-press*
FAP-7021	STBY/POWER	Short-press	Long-press*

\*:A timer counts down the time that remains until the power goes off

When the heading sensor PG-500 (or PG-700) is connected, see the note at the bottom of this page. A beep sounds and the equipment shows product information followed by the results of the startup test. The start up test checks the ROM, RAM and backup of the processor unit and control unit. The test also checks for the presence of heading from the heading sensor and rudder angle information from the rudder reference unit.



\* Or NAVPILOT-711, NAVPILOT-720

\*\* . \*\* : Program version no.

If NG appears for any item, an error message, shown in the table below, appears. Follow the information provided in the message to restore normal operation. If you cannot restore normal operation, contact your dealer for information.

Error message	Meaning
BACK UP DATA IS BROKEN. USE FACTORY DEFAULT. PUSH ANY KEY TO CONTINUE.	Backup data is corrupted.
CAN NOT RECEIVE HEADING DATA. PLEASE CHECK THE HEADING SENSOR. PUSH ANY KEY TO CONTINUE.	Problem with heading sensor.

**Note:** When the Heading Sensor PG-500/PG-700 is connected, turn on the NAVpilot and wait four minutes before you leave port. This allows time for the PG-500/PG-700 heading data to stabilize.

## 1.3 How to Adjust Brilliance, Contrast

### 1.3.1 NAVpilot-700


1. Short-push the **POWER/BRILL** key to show the screen for the adjustment of contrast and brilliance.




2. Operate the **Course control** knob to adjust the contrast. (Contrast can also be adjusted (cyclically) with the **POWER/BRILL** key.)
3. Operate the ◀ or ▶ key to adjust the brilliance.
4. Push the **Course control** knob to close the screen, or wait several seconds for the screen to close automatically.

### 1.3.2 NAVpilot-711, NAVpilot-720

1. Long-push the **TURN/MENU** key to open the menu.



2. Rotate the **Course control** knob to select [CONTRAST/BRILLIANCE] then push the knob. The screen for the adjustment of contrast and brilliance appears.



3. Operate the **Course control** knob to adjust the contrast.
4. Operate the ◀ or ▶ key to adjust the brilliance.
5. Push the **Course control** knob to close the screen, or wait several seconds for the screen to close automatically.


## 1.4 Displays in the STBY and AUTO Modes

There are four (NAVpilot-700) or five (NAVpilot-711, NAVpilot-720) displays to select from in the STBY mode. To select a display, press the **STBY** key or **AUTO** key continuously to step through the displays.

### 1.4.1 Content of displays in the STBY and AUTO modes

#### Navpilot-700

- Autopilot Display 1 (Digital course and heading, and analog and digital rudder angle)
- Autopilot Display 2 (Digital course and heading, analog and digital rudder angle, and one or two nav data displays)
- Nav Data Display (Digital course and heading, and two or three digital nav displays)
- Graphic Display (Digital course and heading, and graphic display)
- Press the **STBY** key to show the displays in the STBY mode.




\*Page no. appears when selecting display.

*Displays (NAVpilot-700)*

1. INTRODUCTION

**Navpilot-711, NAVpilot-720**

- Autopilot Display 1 (Digital course and heading)
- Autopilot Display 2 (Digital course and heading, and digital and analog rudder angle)
- Nav Data Display 1 (Digital course and heading, digital and analog rudder angle, and one nav data display)
- Nav Data Display 2 (Digital course and heading, and one or two digital nav data display)
- Graphic Display (Digital course and heading, and graphic display)
- Press the **STBY** key to show the displays in the STBY mode.



\*Page no. appears when selecting display.

*Displays (NAVpilot-711, 720)*

**Available displays**


The table below shows all the nav data and graphic displays available. Appropriate sensors are required.

<b>Data displayed</b>	<b>Data meaning</b>
<b>Nav data displays</b>	
AIR TEMP	Air temperature
ATMOS PRESS	Atmospheric pressure
BRG	Bearing to waypoint
COG	Course over ground
DATE	Current date
DEWPOINT	Dewpoint
DPT	Depth
ETA	Estimated time of arrival to waypoint
HUMIDITY	Humidity
POS	Position
RNG	Range to waypoint
SOG	Speed over ground
STW	Speed through water
TEMP	Water temperature
TIME	Current time
TRIP	Trip distance
TTG	Time-to-go to waypoint
VOLT	Input/output voltage to processor unit
WIND APPARENT	Apparent wind direction/speed
WIND TRUE	True wind direction/speed
WPT	Waypoint position (Latitude/Longitude)
XTE	Cross-track error
<b>Graphic displays</b>	
COMPASS, RUDDER	Compass rose, and analog and digital rudder angle
DEPTH	Analog and digital depth
ENGINE SPEED	Analog engine speed (revolution meter)
HIGHWAY	Graphic presentation of progress towards waypoint
RUDDER	Analog and digital rudder angle
TEMP	Analog (graph) and digital water temperature
WIND APPARENT	Analog and digital apparent wind direction speed
WIND TRUE	Analog and digital true wind direction speed
<b>Rudder angle, deviation (analog)</b>	
RUDDER	Rudder angle
DEVIATION	Heading deviation

## 1.4.2 Graphic displays


### Compass rose, rudder display

The compass rose and rudder display show ship's heading in graphic form and rudder angle in both analog and digital formats. Requires heading data.




### Depth display

The depth display provides depth data in a graph. Data scrolls across the screen from right to left. Requires depth data.



**Engine speed display**


The engine speed display shows the engine revolution. Requires engine speed data.



9: 9000 rpm


**Highway display**

The highway display provides a graphic presentation of your boat's progress along its intended course. The own ship marker moves according to your boat's track to the waypoint. The cross-track error indication shows the direction and amount your boat is off course. The outlined arrow shows the direction to steer to return to your course and the numeric the distance you are off course. Using the figure below as an example, you would steer left 0.016 nm to return to course. To maintain course, steer the vessel so the own ship marker tracks along the intended course line.




**Rudder display**

The rudder display shows analog and digital rudder angle.




**Water temperature display**

The water temperature display shows water temperature over the selected time interval, and the current water temperature. Data scrolls across the screen from right to left. The interval of time can be selected from the menu. Requires water temperature data.



**Wind display**


The wind display shows wind angle and wind speed. The data can be shown in true wind or apparent wind. The **apparent wind** is the actual flow of air acting upon a sail, or the wind as it appears to the sailor. The **true wind** is the wind seen by a stationary observer in velocity and direction. Requires a wind sensor.




### 1.4.3 How to select the data to display in the STBY mode

In the STBY mode, you can select the nav data or graphic display to show.

1. Short-press the **STBY** key to go to the STBY mode.
2. Press the **STBY** key again to select a display. For example, select the nav data display.



3. Push the **Course control** knob. The cursor selects a data display, as in the illustration shown below.



4. For multi-data display, press ◀ or ▶ to set the cursor on the data to change.
5. Rotate the **Course control** knob to select the data (or graphic). (Graphic displays: Depth graph, Temperature graph, Engine speed, Compass rose, Rudder, Highway, Wind)
6. Push the **Course control** knob to confirm your selection.

## 1. INTRODUCTION


This page is intentionally left blank.

# 2. STEERING MODES


Your NAVpilot has eight primary steering modes: STBY (manual), AUTO, NAV, TURN, FishHunter, DODGE, REMOTE (FU and NFU), and WIND (for sailboats).

## 2.1 STBY Mode

After turning on the power, the equipment goes to the STBY mode. This is a manual steering mode. When sailing into or out of a harbor, steer the vessel in the STBY mode by using the steering wheel (helm) of your boat.



Autopilot display 1 (NAVpilot-700)




Autopilot display 2 (NAVpilot-711, NAVpilot-720)

## 2.2 AUTO Modes

### 2.2.1 AUTO mode

The AUTO mode steers the boat automatically on a course set by the operator.


The AUTO mode will not compensate for the effects of wind or tide, which can push you off course athwart in the ship direction. Use the AUTO mode for short, straight voyages. Otherwise switch to the NAV mode.




To get the AUTO mode, do as follows:

1. Direct the boat toward required course.
2. Press the **AUTO** key to activate the AUTO mode.  
Your boat automatically maintains the current course when the **AUTO** key is pressed.  
When the heading changes from the set course, the NAVpilot automatically adjusts the rudder to return the boat to the set course.
3. To change the course setting in the AUTO mode, rotate the **Course control** knob to the required course.

4. To exit the AUTO mode to steer manually, press the **STBY** key. Steer your boat by the helm.



Autopilot display 1 (NAVpilot-700)




Autopilot display 2 (NAVpilot-711, NAVpilot-720)

## 2. STEERING MODES

### 2.2.2 ADVANCED AUTO mode

The AUTO mode keeps a set course, but your boat's course can change by the effects of tide and wind. To adjust for the effects of tide and wind, use the ADVANCED AUTO mode. The NAVpilot calculates your course according to your current position and heading, and by setting a virtual "waypoint" in its memory to navigate towards. If either tide or wind begins to push you off course, the NAVpilot corrects your heading accordingly.

Your NAVpilot must be connected to a GPS navigator which outputs position data (Latitude and Longitude).





To get the ADVANCED AUTO mode, do as follows:

1. In the AUTO mode, press the **MENU** key to show the menu.
2. Rotate the **Course control** knob to select [ADVANCED AUTO] then push the **Course control** knob to show the advanced auto options window.



3. Rotate the **Course control** knob to select [ON]. (Select [OFF] to quit the ADVANCED AUTO mode.)
4. Push the **Course control** knob to confirm the setting.
5. Press the **MENU** key to close the menu.

You can switch between AUTO and ADVANCED AUTO modes by holding down the **AUTO** key three seconds to show the message "ADVANCED AUTO ON (OFF)" appears.




## 2.3 NAV Mode


NAVpilot steers the vessel towards the current waypoint while compensating for the effects of tide and wind.

When connected to a GPS Navigator, NAVpilot steers the vessel to follow a series of waypoints in sequence. When you arrive at each waypoint or destination, audible and visual alerts are activated.

The NAVpilot takes 15 seconds to activate the NAV mode after the NAVpilot receives the destination information.



*Steering to a single waypoint*



*Steering a route (a series of waypoints)*



### 2.3.1 How to get the NAV mode

To get the NAV mode, do as follows:

1. Set the destination waypoint (or route) on the GPS navigator or chartplotter. (To navigate a route, make sure that your plotter is navigating towards the nearest or required waypoint before you put the NAVpilot into the NAV mode.)
2. Manually steer the boat toward the waypoint.
3. Press the **NAV** key.
4. You are asked if you are sure to navigate to the waypoint selected. Push the **Control course** knob to start to navigate to the waypoint.


**Note 1:** The course reading on the NAVpilot is not always the same as the waypoint direction shown on the chartplotter.

**Note 2:** You can switch between nav data sources (for example, one source fails) by pressing the **NAV** key three seconds. (This feature is not available when [BOTH] is selected as nav data source on the [NAV DATA SOURCE] menu, set during the installation.)



### 2.3.2 Sailing method for the NAV mode

Your vessel can go off course between waypoints in the NAV mode. This can occur when, for example, a command is received from a remote controller. To return to the course set, three methods are available: [COURSE], [XTE (PRECISION)], and [XTE (ECONOMY)]. For [COURSE], the NAVpilot calculates a new course according to your new position, after dodging, etc. that takes you directly to your destination waypoint. [XTE (PRECISION)] and [XTE (ECONOMY)] both use the XTE (cross-track error) value to steer the boat towards your ORIGINAL course before dodging. PRECISION provides for tighter course keeping, within 0.01 nm of the set course. ECONOMY gives less tighter course keeping, within 0.03 nm of the set course.



Select COURSE or one of the XTE selections as shown below.

1. In the NAV mode, press the **MENU** key to show the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [NAV OPTION] then push the knob.
4. Rotate the **Course control** knob to select [NAV MODE] then push the knob to show the NAV mode options window.



5. Rotate the **Course control** knob to select an option then push the knob.
6. Press the **MENU** key three times to close the menu.

### 2.3.3 Waypoint switching method

When you arrive at a waypoint on a route in the NAV mode, you can switch to the next waypoint automatically or manually.

The AUTO setting switches to the next destination waypoint when your boat is within the arrival alarm area (set on the chartplotter). When your boat is within the arrival alarm area, the buzzer sounds for five seconds and the message "WPT WAS CHANGED" appears.

The MANUAL setting requires operator confirmation (pushing the **Course control** knob) before switching to the next waypoint. For manual switching, the NAVpilot sounds a five-second alarm when the vessel arrives at the destination waypoint. The message "PUSH ANY KEY TO TURN." appears. Push any key. Then, the message "WPT WAS CHANGED." appears.

Select waypoint switching method as follows:

1. In the NAV mode, press the **MENU** key to show the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [NAV OPTION] then push the knob to show the related options window.
4. Rotate the **Course control** knob to select [WAYPOINT SWITCHING] then push the knob to show the waypoint switching options window.
5. Rotate the **Course control** knob to select an option then push the knob.
6. Press the **MENU** key three times to close the menu.




### 2.3.4 How to set the steering behavior of your boat after you arrive to a waypoint

The FishHunter mode can be enabled and set up control of the steering behavior of your boat after it reaches the last waypoint in a route. You can choose from orbit, figure eight or square. For details of each movement, see section 2.5.

This function is not available when [BOAT CHARACTERISTICS] (on the Installation menu) is set for [SAILBOAT].

To enable the FishHunter mode and set the steering behavior, do as follows:

1. In the NAV mode, press the **MENU** key to show the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [NAV OPTION] then push the knob.
4. Rotate the **Course control** knob to select [AFTER ARRIVAL] then push the knob to show the after arrival options window.
5. Rotate the **Course control** knob to select an option then push the knob.
6. Press the **MENU** key three times to close the menu.



## 2.4 TURN Mode

The TURN mode provides three preset turning motions: 180°, 360°, and User. These turns are available in the AUTO mode and in clockwise and counterclockwise directions.


For the User turn, you can confirm and change the parameters of the turn before you do the turn. If confirmation or change is not necessary in these turns, simply push the **Course control** knob after selecting the turn with the **TURN** key.

This function is not available when [BOAT CHARACTERISTICS] (on the Installation menu) is set for [SAILBOAT].

### 2.4.1 How to select a turn and start the turn

Select the 180°, 360°, or User turn as follows:

1. Press the **TURN** key to show the Turn menu.





NAVpilot-700



NAVpilot-711/NAVpilot-720

2. Rotate the **Course control** knob to select a turn. The cursor highlights current selection. See the next section for description of turns.



**Note:** You can set the parameters for the User turn (before starting the turn) by pressing the ► key. For details, see section 2.4.4.

3. Push the **Course control** knob to start the turn.

After you start the turn, the steering mode indications shows "XXXT" (XXX=turn angle), the message "BEGINNING TURN" appears, and the buzzer sounds. After the turn is completed, the message "THE TURN ENDED" appears.

To escape from a turn, press the **STBY** key.

### 2.4.2 180° turn

This function changes the current set course by 180° in the opposite direction. This feature is very useful in a man overboard situation and whenever you want to steer back on a reciprocal heading.



### 2.4.3 360° turn

This function also provides a continuous turn feature with a constant rate of turn in a circle. This may be used for circling fish, purse seining, etc.



### 2.4.4 User turn

You can set desired turn angle with this turn, from 15° to 360° in 15° degree increments.

#### How to set the turn angle for the user turn and start the turn

1. Select [USER TURN TO PORT] or [USER TURN TO STBD] from the Turn menu.
2. Press the ► key.



3. The cursor is selecting the value for [TURN ANGLE]; push the **Course control** knob.
4. Rotate the **Course control** knob to set the turn angle then push the knob.
5. To start the turn, rotate the **Course control** knob to select [RUN] then push the knob.

## 2.5 FishHunter Mode

The FishHunter mode is a unique feature of FURUNO's NAVpilot series. Find a fish target with your FURUNO sonar/sounder or bird target with your FURUNO radar and feed it to the NAVpilot. The NAVpilot will activate the FishHunter mode to perform circle, orbit, spiral, figure eight, square or zigzag maneuvers around the specified target.

This function is not available when [BOAT CHARACTERISTICS] (on the Installation menu) is set for [SAILBOAT].

Like with the user turn, you can confirm and change the parameters of a FishHunter turn before you do the turn. If confirmation or change is not necessary, simply push the **Course control** knob after selecting the turn with the **TURN** key.


After you start the turn, the steering mode indication changes as shown in the table below, and the buzzer sounds.

Turn name	Turn mode indication
Circle	CRCL
Orbit	ORBT
Spiral	SPRL AUTO, SPRL NAV, SPRL TLL
Figure-eight	FIG8
Square	SQRE
Zigzag	ZGZG


### 2.5.1 How to preset FishHunter turn parameters

You can preset the parameters for the FishHunter turns as follows:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [FISH HUNTER OPTION] then push the knob.




4. Set the parameters for each turn referring to the figure on the next page.



### 2.5.2 How to select a FishHunter turn and start the turn

1. Press the **TURN** key to show the Turn menu.




NAVpilot-700



NAVpilot-711/NAVpilot-720

2. Rotate the **Course control** knob to select a FishHunter turn. The cursor highlights current selection.

## 2. STEERING MODES



3. If you want to change the parameters for the turn, do 1) - 3) below. If you do not need to change the parameters, push the **Course control** knob to start the turn.

- 1) Press the ► key to show the setting menu for the turn. See section 2.5.5 for details.
- 2) Use the **Course control** knob to set the parameters.
- 3) Select [RUN] then push the knob to start the turn.

The message "START TO TURN BY FISHING MODE" appears, then your boat starts the turn selected.


The orbit and spiral turns require that the speed of the boat be less than 10 knots. If the speed is higher, the message "TOO FAST TO GO TO FISHING MODE. PLEASE SLOW DOWN LESS THAN 10 KN. PUSH MENU KEY TO CANCEL AND GO TO AUTO MODE." appears. Reduce boat's speed to less than 10 knots.

After the turn is completed, the message "THE TURN ENDED" appears.

To escape from the turn, press the **STBY** key.


### 2.5.3 Circle turn

The circle turn can be used for circling fish or a particular object on the seabed. The rate of turn for the circle can be selected on the menu, but it cannot be higher than that set at installation.



### 2.5.4 Orbit turn


In the AUTO mode, your boat orbits around its current position. For the NAV mode, the boat orbits around the (last) waypoint. This function requires a chartplotter or GPS navigator.



### 2.5.5 Spiral turn

The boat spirals in the direction of current heading (STBY), set course (AUTO) or the course to the next waypoint (NAV) that was active at the moment that the spiral turn is started. The spiral speed can be set in the menu. In the NAV mode, the boat steers toward the waypoint(s) spirally. The arrival alarm must also be active on the chartplotter.


The boat will continue to spiral until the **AUTO** or **STBY** key is pressed.



**Note:** If the boat does not enter the arrival alarm area, the NAVpilot does not switch to the next waypoint. To prevent this, set the arrival alarm range as large as possible and activate the perpendicular function on the chartplotter.


### 2.5.6 Figure-eight turn

After the boat has traveled the distance "d" set on the menu, it starts turning in a figure-eight pattern, automatically returning to the position where the figure-eight was initiated. "d", the radius, is set on the menu.




### 2.5.7 Square turn

The square turn is started from a waypoint. You can set length of the sides and the azimuth on the menu.



### 2.5.8 Zigzag turn

The zigzag turn starts from current position. The distance between legs, turn angle, number of turns and how to stop the zigzag turn can be set on the menu. This turn is available in the AUTO and NAV modes.



## 2.6 How to Navigate to a TLL Position

The moment TLL (Target Latitude and Longitude) data is input from a radar or echo sounder in the STBY, AUTO or NAV mode, a dialog box appears (other than sailboat). You may choose how to progress towards that position, from nav mode, spiral and zigzag. (You may also continue current steering mode, by choosing [OFF].) This mode requires position data and waypoint position data.

**NAV mode:** The boat goes to the TLL by the NAV mode.

**Spiral:** The boat goes to the TLL point in a spiral pattern.

**Zigzag:** The boat follows a zigzag pattern to the TLL.



## 2.7 REMOTE Mode

Four types of optional remote controllers can be connected to your NAVpilot to control the NAVpilot from a remote location.


### 2.7.1 Dial-type remote controller (FAP-5551, FAP-5552)

These are FU-type remote controllers, and they can be used in the AUTO and NAV modes. The rudder moves until operation of the remote controller is stopped.


1. Turn the switch on the remote controller to show "FU RC" (Remote Controller) on the control unit. If the remote controller switch is turned on when in the STBY mode, a beep sounds to alert you that the remote mode is not available.



2. Rotate the dial on the remote controller to set the rudder angle.



3. To turn off the REMOTE mode, turn off the remote controller




Control is returned to the main control unit and the mode that was originally active (AUTO or NAV) is restored. For the NAV mode, the boat will go to the destination waypoint based on the (COURSE or XTE) nav steering method menu setting.

### 2.7.2 **Button-type remote controller (FAP-6211, FAP-6212), Dodge-type remote controller (FAP-6231, FAP-6232), Lever-type remote controller (FAP-6221, FAP-6222)**

These controllers can be used in the STBY, AUTO and NAV modes. (The dodge-type controller is not shown.)

The button-type controller has an ON/OFF switch and works like an NFU remote controller and a dodge remote controller. In the NFU mode the user operates the remote controller to move the rudder and the rudder stops once operation of the remote controller is stopped. The dodge-type remote controller sets your course and the rudder is moved to steer the set course.


1. For button-and lever-type remote controllers, turn on the remote controller. The dodge-type remote controller doesn't have a power switch, it can be operated by simply pressing the direction buttons.



*How to power button-and lever-type remote controllers*


## 2. STEERING MODES

The indication "NFU RC" (Remote Controller) appears on the control unit.





*Autopilot display in NFU mode (example: NAVpilot-700)*

- For button-and-dodge-type remote controllers, press the ◀ or ▶ key on the remote controller. For the lever-type, position the lever for the direction.



3. For the button-and lever-type remote controllers, turn off the remote controller to terminate the REMOTE mode. For the dodge-type remote controller, simply release a key. Control is returned to the control unit and the previously used mode (STBY, AUTO or NAV).



*How to power off button-and lever-type remote controllers*


## 2.8 DODGE Mode

The DODGE mode is useful in situations where you need to quickly take control of the helm to avoid an obstruction.

### 2.8.1 How to dodge in the STBY mode

Press the ◀ or ▶ key down to steer appropriately until the boat has cleared the obstruction. The equipment goes into the DODGE mode (from STBY to DODGE mode the mode indication shows "NFU"\* (Non-Follow Up) while pressing the ◀ or ▶ key. Steering can not be done from other control units or remote controllers. Further the audible alarm sounds when one of the above keys is operated, to alert you to dodge operation. The steering mode indication shows [DODG]. If the **Course control** knob is operated, the display shows "FU" and the rudder is moved until you stop operating the knob. To escape from the FU or NFU mode, press the **STBY** key.

\* Non-Follow up (NFU) is a manual steering mode that moves the rudder as long as the ◀ or ▶ key is operated.



**Note:** To go the FU mode, press the ◀ and ▶ keys together. (The FU mode drives the rudder while the ◀ or ▶ key is operated.)

To quit the DODGE mode, release the ◀ or ▶ key.

### 2.8.2 How to dodge in the AUTO and NAV modes


Press the ◀ or ▶ key down to steer appropriately until the boat has cleared the obstruction. The equipment goes into the DODGE mode and the audible alarm sounds when one of the above keys is operated, to alert you to dodge operation. Note also that "DODG" appears on the display.

**Note:** In the AUTO mode, the ◀ and ▶ keys can be used to change the course degree by 5° or 10° or user setting (1°-90°, one-degree steps) steps depending on the installation setting. It is useful when you need to affect a large course change rapidly. However, the DODGE mode becomes inoperative when this function is activated. For details, ask your serviceman.

## 2.9 WIND Mode (for sailboats)


In the WIND mode, the NAVpilot steers the boat based on the wind angle. The NAVpilot consistently maintains the preset angle between ship's heading and wind direction (true or apparent), while eliminating the effects of turbulence and short term wind variations.

The WIND mode requires wind sensor data and the ship's characteristic (set on the menu at installation) must be set for "sailboat."



### 2.9.1 How to get the WIND mode

1. Direct the heading to the desired direction and trim the sail to keep the wind direction, in the AUTO mode.
2. Press the **AUTO** key while holding the **STBY** key down to activate the WIND mode.
3. Set the wind angle by rotating the **Course control** knob.
4. To escape from the WIND mode, press the **STBY** key.




### 2.9.2 Wind angle mode

There are three wind angle modes: AWA (Apparent Wind Angle), TWA (True Wind Angle), and AUTO.

**AWA:** The boat is steered so that the apparent wind angle is constant. AWA mode requires wind angle and speed data from a wind sensor. Use this mode when wind is stable.

**TWA:** The boat is steered so that the true wind angle (in relation to ship's bow) is constant. This mode requires apparent wind angle, apparent wind speed, your boat's speed and heading. Use this mode when there is an unstable downwind.

**AUTO:** When the wind direction goes higher than the "mode type" setting (see the procedure below), TWA is selected. When the wind direction is less than the set value, AWA is selected.



NOTICE

**When running on engine, use the TWA (or AUTO) mode.**

The autopilot cannot control your boat when its speed exceeds the true wind speed in AWA mode, which can lead to a potentially dangerous situation.

To select the wind angle mode, do the following:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the **Course control** knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select [MODE TYPE] then push the knob.
5. Rotate the **Course control** knob to select an option then push the knob. For [AUTO] go to the next step. For [AWA] or [TWA] go to step 7.
6. **For the AUTO mode**, do the following to set the wind angle at which switching occurs between TWA and AWA modes.
  - 1) Rotate the **Course control** knob to select the wind angle value to the right of [AUTO] then push the **Course control** knob.
  - 2) Rotate the **Course control** knob to set the threshold value for switching between AWA and TWA then push the knob.
7. Press the **MENU** key three times to close the menu.

WIND OPTION

MODE TYPE: **AWA**

WIND TACK RUD ANGLE: 35°

WIND DAMPING: OFF

FIXED TACK ANGLE: 20°

RATE OF SLOW TACK: 3°/s

RATE OF FAST TACK: 20°/s

TACK TIMER: OFF

**AWA**

TWA

AUTO

### 2.9.3 TACK mode


The TACK mode provides various tacking and gybing motions with the **TURN** key. Fixed and auto tacking are available.

#### Tacking/gybing (fixed tack)


This function changes the current course by the degrees (set on menu) to port or starboard direction. There are two types of speed, SLOW (for gybing) and FAST (for tacking) in this mode. Use the tack mode when the true wind angle is less than 90°.

To start tacking/gybing, do the following:

1. Press the **AUTO** key to get the AUTO mode.
2. Press the **TURN** key to show the Turn menu.




NAVpilot-700



NAVpilot-711 NAVpilot-720

3. Rotate the **Course control** knob to select a turn.  
**SLOW TURN TO PORT or SLOW TURN TO STBD:** For gybing, when the wind angle is larger than 120°. The boat slowly changes the heading angle.  
**FAST TURN TO PORT or FAST TURN TO STBD:** For tacking, when the true wind angle is less than 90°. The boat rapidly changes the heading angle.



4. Push the **Course control** knob to start the turn.  
 The steering mode indication shows [BEGINNING TURN]. When the turn starts, three beeps sound. You can set the timing between pressing the **Course control** knob and starting tacking. See "How to set the tack timer" on page 2-29.
5. While confirming your heading, do jib sheet creasing and trimming operations.  
 Your boat starts turning in the direction selected at step 3
  - The tacking angle can be set on the menu. See "How to set the fixed tack angle" on the next page.
  - When the turning is completed, a beep sounds three times and the message "THE TURN ENDED" appears.

## 2. STEERING MODES

### How to set the rate of turn for FAST and SLOW tacking

The rate of turn is preset as 3° for SLOW and 20° for FAST. If you need to change the value, do the following:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the **Course control** knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select the value shown for [RATE OF SLOW TACK] then push the knob.
5. Rotate the **Course control** knob to set the rate then push the knob.
6. Rotate the **Course control** knob to select the value shown for [RATE OF FAST TACK] then push the knob.
7. Rotate the **Course control** knob to set the rate then push the knob.
8. Press the **MENU** key three times to close the menu.


### How to set the fixed tack angle

The fixed tacking mode requires the setting of tacking angle. Set the angle as follows:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the **Course control** knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select the value shown for [FIXED TACK ANGLE] then push the knob.
5. Rotate the **Course control** knob to set the angle then push the knob.
6. Press the **MENU** key three times to close the menu.


### 2.9.4 Tacking in WIND mode (WIND TACK)


In the WIND mode, the degree and direction of tacking are automatically set so that the boat receives the apparent wind on its opposite side with the same angle.



To start turning, do the following:

1. In the WIND mode, press the **TURN** key to show the Turn menu.  
The turning direction is determined according to the heading at the time the key is pressed, as shown below.




 : Direction available to turn

2. Rotate the **Course control** knob to select the direction to turn.  
The choices are "TURN TO PORT" and "TURN TO STBD" (starboard). If you select an unavailable direction, the message "WIND DIRECTION OUT OF RANGE FOR YOUR CHOICE." appears and the selection is refused.

## 2. STEERING MODES

3. Push the **Course control** knob to start the turn.  
The boat starts turning toward the selected direction until the heading changes twice that set when the **Course control** knob was pressed. When the **Course control** knob is pressed, for example, at the P (port) 50°, the boat turns until the heading decreases 100°.



*Tacking maneuver when wind angle is 50°*

You can set the tacking start timing between pressing the **Course control** knob and the start of turning. For details, see "How to set the tack timer" on page 2-29.

4. When the turning is completed, a beep sounds three times.

### **How to set maximum rudder angle for wind tacking**

The tacking in the WIND mode requires the setting of maximum rudder angle. This angle is calculated automatically when the NAVpilot is installed. If you need to change the value, do the following:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select the value shown for [WIND TACK RUD ANGLE] then push the knob.
5. Rotate the **Course control** knob to set the angle then push the knob.
6. Press the **MENU** key three times to close the menu.

**How to set the damping interval for wind data**

You can set the damping interval for wind data to compensate for random fluctuation in wind data. The higher the setting the more “smooth” the data. However, a high damping interval causes delay in receiving wind data; the amount of delay equivalent to the damping interval. Turn off wind damping if the wind data is received stably.

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select the current setting for [WIND DAMPING] then push the knob.



5. Rotate the **Course control** knob to select [ON] then push the knob.
6. Rotate the **Course control** knob to select the current wind damping interval then push the knob.
7. Rotate the **Course control** knob to set the interval then push the knob. The setting range is 0.7 to 99 (sec.).
8. Press the **MENU** key three times to close the menu.

**How to set the tack timer**

You can set the amount of time to wait before starting a turn, after pushing the **Course control** knob.

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [WIND OPTION] then push the knob.
4. Rotate the **Course control** knob to select the value shown for [TACK TIMER] then push the knob to show the tack timer options.



5. Rotate the **Course control** knob to select [ON] then push the knob.
6. Rotate the **Course control** knob to select the current timer value then push the knob.
7. Rotate the **Course control** knob to set the timer value then push the knob. The setting range is 1-99 (sec.).
8. Press the **MENU** key three times to close the menu.

## 2. STEERING MODES

This page is intentionally left blank.

# 3. ALARMS

Your NAVpilot has eight conditions which generate both audio and visual alarms: watch alarm, deviation alarm, XTE (cross-track error) alarm, wind alarm (four types, sailboats only), speed alarm, depth alarm, water temperature alarm, and log trip alarm.


When an alarm is violated, the buzzer sounds, and the alarm icon (🚨) and a pop-up message display appear (see section 5.5.3). You can see which alarm(s) has been violated by opening the Alarm Log, from the [SYSTEM SETUP] menu.

## 3.1 ALARM Menu


All alarm operations are done from the [ALARM] menu. To show the [ALARM] menu, do as follows:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [ALARM] then push the knob.

Page 1



Page 2



\* Appears when Ship's Characteristics is set for "Sailboat".

### 3.2 Alarm Buzzer

You can select the buzzer from which to output the audio alarm as follows. Use the external buzzer if the volume of the internal buzzer is not loud enough.

1. Rotate the **Course control** knob to select [BUZZER] from the ALARM menu then push the knob.
2. Rotate the **Course control** knob to select [INTERNAL] or [INTERNAL+EXTERNAL] then push the knob.  
[INTERNAL]: Buzzer in Control Unit sounds.  
[INTERNAL+EXTERNAL]: Buzzer in control unit and external buzzer sound.
3. Push the **Course control** knob to confirm setting.



### 3.3 Buzzer Interval

The sound pattern for the alarms can be selected as follows.

1. Rotate the **Course control** knob to select [BUZZER INTERVAL] from the [ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [SHORT], [LONG] or [CONTINUOUS] then push the knob. [CONTINUOUS] releases the buzzer continuously.



3. Push the **Course control** knob to confirm setting.

## 3.4 Watch Alarm

The watch alarm periodically warns the helmsman to check the NAVpilot when in the AUTO or NAV mode.

1. Rotate the **Course control** knob to select [WATCH ALARM] from the [ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [OFF] or [ON] then push the knob. For [OFF] got to step 5.
3. Rotate the **Course control** knob to select the current watch alarm value then push the knob.
4. Rotate the **Course control** knob to set the time interval (1 to 99 min).
5. Push the **Course control** knob to confirm setting.

If the set time passes without operation, the buzzer sounds. Further, if three minutes elapses after the watch alarm has sounded, the message "THE SET TIME HAS PASSED" appears and the alarm becomes louder. Press any key to clear the alarm.


## 3.5 Deviation Alarm

The deviation alarm sounds in the AUTO and NAV modes when the heading deviates more than the deviation alarm value.

1. Rotate the **Course control** knob to select the current setting for [DEVIATION ALARM] from the [ALARM] menu then push the knob.
2. Rotate the **Course control** knob to set the degree of deviation then push the knob.

## 3.6 XTE Alarm

The XTE alarm, which is available in the NAV mode, alerts you when the course error has exceeded the XTE alarm setting.




1. Rotate the **Course control** knob to select [XTE ALARM] from the [ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [OFF] or [ON] then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.
3. Rotate the **Course control** knob to select the current XTE alarm value then push the knob.
4. Rotate the **Course control** knob to set the XTE alarm value.
5. Push the **Course control** knob to confirm setting.

## 3.7 Arrival Alarm

The arrival alarm alerts you when you are within a specific distance from a waypoint.



1. Rotate the **Course control** knob to select [ARRIVAL ALARM] from the [ALARM] menu then push the knob.




2. Rotate the **Course control** knob to select [OFF] or [ON] then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.
3. Rotate the **Course control** knob to select the current arrival alarm value then push the knob.
4. Rotate the **Course control** knob to set the arrival alarm value.
5. Push the **Course control** knob to confirm setting.

## 3.8 Speed Alarm

The speed alarm warns you when the speed of your boat is within, outside, over or under the speed range setting. Requires speed data.

1. Rotate the **Course control** knob to select [SPEED ALARM] from the [ALARM] menu then push the knob.




2. Rotate the **Course control** knob to select an option then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.
  - [OFF]: Turn the alarm off.
  - [UNDER]: Alarm sounds when ship's speed is under the set value.
  - [OVER]: Alarm sounds when ship's speed is over the set value.
  - [INSIDE]: Alarm sounds when ship's speed is within the speed range set.
  - [OUT]: Alarm sounds when ship's speed is outside the range set.
3. Rotate the **Course control** knob to set value.
  - For [INSIDE] and [OUT OF RANGE], set the upper and lower limits for the alarm.
  - For [OVER] and [UNDER], set a value.
4. Push the **Course control** knob to confirm setting.

## 3.9 Depth Alarm

The depth alarm warns you when the bottom is shallower, deeper within or outside the depth alarm setting. Requires a depth sensor.

1. Rotate the **Course control** knob to select [DEPTH ALARM] from the [ALARM] menu then push the knob.




2. Rotate the **Course control** knob to select an option then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.  
 [OFF]: Turn the alarm off.  
 [SHALLOW]: Alarm sounds when depth is less than the set value.  
 [DEEP]: Alarm sounds when depth is greater than the set value.  
 [INSIDE]: Alarm sounds when depth is within the depth range set.  
 [OUT OF RANGE]: Alarm sounds when depth is outside the range set.
3. Rotate the **Course control** knob to set value.  
 For [INSIDE] and [OUT OF RANGE], set the upper and lower limits for the alarm.  
 For [SHALLOW] and [DEEP], set a value.
4. Push the **Course control** knob to confirm setting.

## 3.10 Water Temperature Alarm

There are five types of water temperature alarms: [UNDER], [OVER], [INSIDE], [OUT OF RANGE] and [SHEAR]. Requires a water temperature sensor.

1. Rotate the **Course control** knob to select [TEMP ALARM] from the [ALARM] menu then push the knob.
2. Rotate the **Course control** knob to select an option then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.  
 [OFF]: Turn the alarm off.  
 [UNDER]: Alarm sounds when water temperature is less than the set value.  
 [OVER]: Alarm sounds when water temperature is higher than the set value.  
 [INSIDE]: Alarm sounds when water temperature is within the depth range set.  
 [OUT OF RANGE]: Alarm sounds when water temperature is outside the range set.  
 [SHEAR]: Alarm sounds when the temperature changes over the value set within a minute.
3. Rotate the **Course control** knob to set value.  
 [INSIDE], [OUT OF RANGE]: Set the upper and lower limits for the alarm.  
 [OVER], [UNDER], [SHEAR]: Set a value.
4. Push the **Course control** knob to confirm setting.



## 3.11 Trip Distance Alarm, Trip Distance Reset

### 3.11.1 How to set the log trip alarm

The log trip alarm alerts when you have traveled a specific distance.

1. Rotate the **Course control** knob to select [LOG TRIP] from the [ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [OFF] or [ON] then push the knob. For [OFF], press the **MENU** key consecutively to close the menu.
3. Rotate the **Course control** knob to set a value.
4. Push the **Course control** knob to confirm setting.

### 3.11.2 How to reset the trip distance

Follow the procedure below to reset the trip distance to zero.

1. Rotate the **Course control** knob to select [LOG TRIP CLEAR] from the [ALARM] menu then push the knob.




2. Rotate the **Course control** knob to select [YES] then push the knob.
3. Push the **Course control** knob reset the trip distance to zero.

## 3.12 Wind Alarms (for sailboats)

The WIND alarm, which is an alarm exclusively for sailboats, has four conditions which generate both audio and visual alarms: heading change, wind shift, true wind speed and apparent wind speed.


To access the [WIND ALARM] menu, do the following:

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [ALARM] then push the knob.
4. Rotate the **Course control** knob to select [WIND ALARM] then push the knob.



### 3.12.1 Heading change alarm

The heading change alarm sounds when own boat's heading changes remarkably by the effects of true wind angle. Set the heading value and alarm range as shown in the procedure which follows.



1. Rotate the **Course control** knob to select [HEADING CHANGE ALARM] from the [WIND ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [ON] then push the knob. The line below [HEADING CHANGE ALARM] shows two values.
3. Rotate the **Course control** knob to select the value (heading) at the far left then push the knob.
4. Rotate the **Course control** knob to set value then push the knob to confirm setting.
5. Rotate the **Course control** knob to select [BND] and then push the knob.
6. Rotate the **Course control** knob to set value then push the knob to confirm setting.

### 3.12.2 Wind shift alarm

The wind shift alarm sounds when the current wind angle is greater than the wind angle limit set.

1. Rotate the **Course control** knob to select the value for [WIND SHIFT ALARM] from the [WIND ALARM] menu then push the knob.
2. Rotate the **Course control** knob to set value then push the knob to confirm setting.

### 3.12.3 True wind speed alarm

The true wind speed alarm warns you when the true wind speed is over or under the true wind speed alarm setting.

1. Rotate the **Course control** knob to select [TRUE WIND SPD ALARM] from the [WIND ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [ON] then push the knob.
3. Rotate the **Course control** knob to select the current true wind speed alarm value then push the knob.
4. Rotate the **Course control** knob to set the upper and lower limits for the alarm then push the knob to confirm setting.

### 3.12.4 Apparent wind speed alarm

The apparent wind speed alarm warns you when the apparent wind speed is over or under the apparent wind speed alarm setting.


1. Rotate the **Course control** knob to select [APP WIND SPD ALARM] from the [WIND ALARM] menu then push the knob.



2. Rotate the **Course control** knob to select [ON] then push the knob.
3. Rotate the **Course control** knob to select the current apparent wind speed alarm value then push the knob.
4. Rotate the **Course control** knob to set the upper and lower limits for the alarm then push the knob to confirm setting.

### 3.13 Alarm Log

The Alarm Log shows the date, time and alarm no. of violated alarms. To show this log, select [ALARM LOG] from the [SYSTEM SETUP] menu. For a list of alarm numbers, see section 5.5.3.




# 4. HOW TO CUSTOMIZE YOUR NAVPILOT

---


This chapter shows you to customize your NAVpilot to suit the characteristics of your boat and your operational needs.

The items shown in each menu depend on the mode in use. For the STBY mode the complete menu is shown. In the AUTO, NAV or WIND mode, only the menu items related to those modes are shown.

In the STBY mode, press the **MENU** key to show the STBY mode menu.




*NAVpilot-700*



*NAVpilot-711/720*

## 4.1 Parameter Setup (PARAMETER SETUP Menu)

The various parameters for your NAVpilot are set up from the [PARAMETER SETUP] menu, which is in the [OTHER MENU].



*NAVpilot-700*

*\* Appears on page 2 of menu for NAVpilot-711/720.*

### 4.1.1 Sea state

Your NAVpilot has an automatic adjustment feature which sets up the equipment according to ship's characteristics and sea state, for optimum performance in the AUTO, NAV and WIND modes. In addition, a self-learning algorithm is incorporated: Parameters for rudder ratio, counter rudder and auto trim gains are constantly optimized based on the steering history of your boat, and are stored in memory for future navigation.

#### How to select NAVpilot steering parameters

Set how the NAVpilot steers your boat as follows:

1. Rotate the **Course control** knob to select [SEA STATE] then push the knob.



2. Rotate the **Course control** knob to select the option which best matches current sea state then push the knob. For items other than [FULL-AUTO], go to step 4.  
[FULL-AUTO]: Auto adjustment and self-learning are on.  
[SEMI-AUTO]: Auto adjustment is on, self-learning is off.  
[MANUAL-CALM]: Self-learning is off, using the parameter selected for calm sea.  
[MANUAL-MODERATE]: Self-learning is off, using the parameters for a typical normal sea state.  
[MANUAL-ROUGH]: Self-learning is off, using preset parameters for a typical rough sea state.

For normal, everyday operation, the [FULL-AUTO] mode is recommended. However, if you want the NAVpilot to steer the boat based on experience-related parameters, but you don't want the pilot to be in "self-learning" mode, choose the [SEMI-AUTO] option.

Note that the course keeping quality may be decreased if the sea state is different from the experience-related parameters. This option is provided if you happen to be using the pilot in a situation that you do not anticipate encountering again.

3. For [FULL-AUTO], set the deviation level as follows:
  - 1) Rotate the **Course control** knob to select [DEVIATION LEVEL] then push the knob.



- 2) Rotate the **Course control** knob to select [AUTO] or [LEVEL]. For [LEVEL], you may set a value between 1 and 9. A lower number keeps the course more precisely but the rudder may be turned more often. With a higher number, the rudder is fixed, but the course may not be kept as precisely.
4. Push the **Course control** knob to confirm setting.

### How to manually set NAVpilot steering parameters

When [MANUAL-CALM], [MANUAL-MODERATE] or [MANUAL-ROUGH] is selected as the sea state, set [MANUAL PARAMETERS] as below.

You can set three parameters for the MANUAL function: Weather, Rudder gain and Counter rudder.

1. Rotate the **Course control** knob to select [MANUAL PARAMETERS] from the [PARAMETER SETUP] menu then push the knob. The display now looks like the one shown below.


	SEA STATE		
	[CALM]	[MODERATE]	[ROUGH]
[WEATHER]	1°	2°	3°
[RUDDER GAIN]	3	5	10
[COUNTER RUDDER]	1	2	4

2. Rotate the **Course control** knob to select the setting of [WEATHER-CALM] then press the knob.
3. Rotate the **Course control** knob to set value (0° to 10° for weather).
4. Push the **Course control** knob.
5. Set [WEATHER-MODERATE], [WEATHER-ROUGH] and [RUDDER GAIN] and [COUNT RUDDER] similarly (setting range: 0-10 for weather, 1-20 for rudder gain, and 0-20 for counter rudder).
6. Press the **MENU** key to finish.

#### Guidelines for how to set SEA STATE

**[WEATHER]:** When the sea is rough, the boat's heading fluctuates to port and starboard. If the rudder is driven very often to maintain the set course, the helm mechanism may wear out. To prevent this, the weather adjustment makes the NAVpilot insensitive to minute course deviations. You may choose a degree between 1° to 10°. Until the course deviation exceeds the selected setting, steering to correct the heading will not be initiated.

The illustration at the top of the next page shows boat's track lines with weather setting 3° and 7°. When 7° is set, for example, the rudder is not driven until the course deviation exceeds 7°. Increasing the setting reduces activation of the steering gear, however the boat tends to zigzag. When the sea is calm, set a smaller value.



#### 4. HOW TO CUSTOMIZE YOUR NAVPILOT

**[RUDDER GAIN]:** When the boat's heading deviates from the set course, the NAVpilot adjusts the rudder to correct it. The rudder angle (number of degrees) which is steered against every degree of course deviation is known as the rudder gain.


The following illustrations show how many degrees the NAVpilot steers the rudder in order to nullify 4 degrees of course deviation with various settings of the rudder gain.

Rudder gain =  $1^\circ$



Rudder angle =  $4^\circ \times 1 = 4^\circ$

Rudder gain =  $2^\circ$




Rudder angle =  $4^\circ \times 2 = 8^\circ$

Rudder gain =  $3^\circ$




Rudder angle =  $4^\circ \times 3 = 12^\circ$

Set rudder gain so that the boat does not make frequent yaw. The figure shown below provides general guidelines for setting rudder gain.



**[COUNTER RUDDER]:** If the boat is heavily loaded, the heading could change excessively because of inertia. This phenomenon causes the vessel to "overshoot" the intended course. If this happens, the NAVpilot will steer the rudder to the opposite side and the heading will turn in opposite direction excessively again. In an extreme case the heading oscillates several times until it finally settles in the new course. An adjustment known as "counter rudder" prevents this kind of oscillation.

Counter rudder is usually not required for small boats. When your boat zigzags a lot before settling in the new course, increase the counter rudder setting.



### 4.1.2 Trim gain

The NAVpilot continually monitors the boat's trim in order to keep the trim sensitivity optimum. A lower setting is common because boat's trim usually does not change quickly. A large number changes the trim compensation value more frequently. Too high of a setting may result in the following problems.

- Trim sensitivity is over-affected, resulting that a trim appears in both port and starboard directions alternately.
- Trim compensation mechanism responds to the yawing, resulting in more serious oscillation of ship's heading.

To automatically set the trim, do as follows:

1. Rotate the **Course control** knob to select [TRIM GAIN] from the [PARAMETER SETUP] menu.
2. Push the **Course control** knob to show the options for [TRIM GAIN].
3. Rotate the **Course control** knob to select [AUTO] or [MANUAL] then push the knob. For [AUTO] go to step 6.
4. Rotate the **Course control** knob to select the current value and push the knob.
5. Rotate the **Course control** knob to set a value (1 to 20, the default value is automatically calculated according to length of your boat, entered on the [SHIP'S CHARACTERISTICS] menu at installation.
6. Push the **Course control** knob to finish.



### 4.1.3 Speed calculation

Speed is normally entered automatically, from your navigator. If the navigator fails, manually enter speed.

1. Rotate the **Course control** knob to select [SPEED CALCULATION] from the [PARAMETER SETUP] menu.
2. Push the **Course control** knob to show the options for [SPEED CALCULATION].



3. Rotate the **Course control** knob to select [AUTO] or [MANUAL] then push the knob. For [AUTO] go to step 4. For [MANUAL], do as follows:
  - 1) Rotate the **Course control** knob to select the current value then push the knob.
  - 2) Rotate the **Course control** knob to set a value (0.1 - 99.0).
4. Push the **Course control** knob to finish.

## 4.2 Net Towing

When a boat is towing fishing gear its stern is "dragged" by the net. This causes the boat to stray from its intended course. To keep the boat on course, you need to adjust the trim manually, which can be bothersome. If you do not want to be bothered with trim adjustments, you can enable the automatic towing function to have the trim automatically adjusted. This feature is useful for trawlers and purse seiners.

1. Open the [OTHER MENU] followed by the [AUTO OPTION] menu.
2. Rotate the **Course control** knob to select [NET TOWING AUTO] then push the knob.




3. Rotate the **Course control** knob to select [OFF] or [ON].
4. Push the **Course control** knob to finish.

Note that you must keep the boat on a straight course before the AUTO mode is selected.

### 4.3 Course After Operation of a Remote Controller

Select the course to follow after a remote controller is operated.



1. Open the [OTHER MENU] followed by the [AUTO OPTION] menu.
2. Rotate the **Course control** knob to select [CSE AFTER REMOTE] then push the knob.




3. Rotate the **Course control** knob to select desired option.
4. Push the **Course control** knob to finish.

### 4.4 Nav Data Source

Select the source of nav data to use in the NAV mode.

1. Select [OTHER MENU] followed by [NAV OPTION].
2. Rotate the **Course control** knob to select [NAV DATA SOURCE] then push the knob.



3. Rotate the **Course control** knob to select [DATA SOURCE] then push the knob.



4. Rotate the **Course control** knob to select source then push the knob. If you have more than one source of nav data, you can select [BOTH]. In this case, the nav data fed by [SOURCE2] is used when that of [SOURCE1] is not available.

#### 4. HOW TO CUSTOMIZE YOUR NAVPILOT

5. Rotate the **Course control** knob to select [SOURCE1] then push the knob.



If you have some equipment which outputs nav data, the name appears in the window. In the example above, a NAVNet3 equipment, with unique number of 000C2F, is connected.

6. Rotate the **Course control** knob to select source then push the knob. If you have more than one device that outputs nav data, you can select it at [SOURCE2].

**Note:** If you have NAVnet vx2 equipment connected and it is synchronized with the NAVpilot ([NAVNET2] turned on in the [AUTO OPTION] menu, [SOURCE2] is automatically selected.

## 4.5 NAVnet vx2 Synchronization

The NAVpilot goes to the NAV mode when it receives a P sentence (proprietary FURUNO sentence) from a NAVnet vx2 equipment. For example, “autopilot information”. You can turn this feature on or off as follows:

1. Open the [OTHER MENU] followed by the [NAV OPTION] menu.
2. Rotate the **Course control** knob to select [NAVNET2] then push the knob.



3. Rotate the **Course control** knob to select [OFF] or [ON].
4. Push the **Course control** knob to finish.

## 4.6 SYSTEM SETUP Menu

The [SYSTEM SETUP] menu provides various functions which once set do not require frequent adjust. Set the items in this menu according to operational needs, current environment, etc. To open this menu, select [OTHER MENU] followed by [SYSTEM SETUP].

<p>Page 1</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">SYSTEM SETUP</p> <p>KEY BEEP: <b>OFF</b></p> <p>BUZZER VOL: LARGE</p> <p>ARROW KEY: DODGE</p> <p>TURN ANGLE: 15</p> <p>KEY LOCK: UNLOCK</p> <p>PANEL DIMMER: 8</p> <p>PASSWORD: 0000</p> <p>PASSWORD FUNCTION: OFF</p> </div>	<p>Page 2</p> <div style="border: 1px solid black; padding: 5px;"> <p>RECEIVE SCREEN: <b>OFF</b></p> <p>SAVE USER SETTING: NO</p> <p>LOAD USER SETTING: NO</p> <p>SAVE DISPLAY SETTINGS: NO</p> <p>LOAD DISPLAY SETTINGS: NO</p> <p>ALARM LOG</p> <p>SIM/DEMO: OFF</p> <p>DIAGNOSTIC: OFF</p> <p>DISPLAY DATA SELECT MENU</p> </div>
<p>Page 3</p> <div style="border: 1px solid black; padding: 5px; min-height: 100px;"> <p>SYSTEM DATA</p> </div>	

*SYSTEM SETUP menu (shown: NAVpilot-700)*

### SYSTEM SETUP menu description


Item	Description	Options
[KEY BEEP]	Turn the key beep on or off.	[ON], [OFF]
[BUZZER VOL]	Set the volume of the buzzer, on the NAVpilot-700.	[SMALL], [LARGE]
[ARROW KEY]	Set the function of an arrow key when pressed to dodge an obstruction in the AUTO and NAV modes.	[DODGE], [5°], [10°], [MANUAL]. For [MANUAL], select degree of turn from 1°-90°.
[TURN ANGLE]	Set the angle of turn in the Turn mode.	15°-360°, 15° steps
[KEY LOCK]	Prevent operation of the control unit.	[LOCK], [UNLOCK]. The "LOCK" icon (🔒) appears when [LOCK] is selected.
[PANEL DIMMER]	Set the backlighting level for the panel dimmer.	1-8
[PASSWORD]	Assign a four-digit password to use to unlock the keys and menu on the control unit.	0000-9999

#### 4. HOW TO CUSTOMIZE YOUR NAVPILOT

Item	Description	Options
[PASSWORD FUNCTION]	Activates or deactivates password requirement.	[ON], [OFF]
[RECEIVE SCREEN]	For multiple control units, you can copy the settings of one control unit to another. When you receive settings from a control unit of a different size than own, the following rule applies: <u>1DIN</u> <u>2DIN</u> 1BOX      2BOXES 2BOXES   3BOXES	[NO], 1-6 (actual number depends on number of control units connected)
[SAVE USER SETTINGS]	Save current settings as user default settings.	[NO], [YES]
[LOAD USER SETTINGS]	Load user default settings. The equipment is automatically restarted to restore saved user settings.	[NO], [YES]
[SAVE DISPLAY SETTINGS]	Save all display-related settings.	[NO], [YES]
[LOAD DISPLAY SETTINGS]	Load currently saved display-related settings.	[NO], [YES]
[ALARM LOG]	Show the alarms generated. See section 3.13 Alarm Log.	
[SIM/DEMO]	Activate and deactivate the demonstration mode. DO NOT use this function on board your boat; it is intended for use by service technicians. "SIM" appears at the top right corner when the simulation mode is enabled.	[OFF], [DEMO], [EASY-SIM], [RUDDER-SIM].
[DIAGNOSTIC]	Perform various diagnostics on the NAVpilot system. See section 5.3 Diagnostics.	
[DISPLAY DATA SELECT MENU]	Set and select the data to show in the AUTO, NAV, WIND, and FISH HUNTER modes. See the next two pages for the procedure.	
[SYSTEM DATA]	Show system data. See section 5.4 System Data.	

**How to preset data for the data display in the STBY and AUTO modes**


1. Open the [SYSTEM SETUP] menu, select [DISPLAY DATA SELECT MENU] then push the **Course control** knob.




2. The cursor is selecting the setting of [PATTERN]; push the **Course control** knob.



3. Rotate the **Course control** knob to select a pattern number then push the knob.  
Pattern no. and default data:  
Pattern 1: SOG (Speed Over Ground), POS (Position)  
Pattern 2: SOG (Speed Over Ground), COG (Course Over Ground)  
Pattern 3: SOG (Speed Over Ground), XTE (Cross-track Error)
4. Rotate the **Course control** knob to select [DISPLAY 1] then push the knob.



Page 1




Page 2

*Nav data options (arrangement as shown on NAVpilot-700)*

5. Rotate the **Course control** knob to select nav data then push the knob.
6. Set other patterns similarly.
7. Press the **MENU** key four times to close the menu.

**How to select the display data pattern to show in the STBY and AUTO modes**

1. In the AUTO mode, push the **Course control** knob to show the menu which follows.



2. Rotate the **Course control** knob to select a pattern number then push the knob. The indication at [DISPLAY 1] and [DISPLAY 2] changes according to pattern selected.


## 4.7 Menu Shortcuts

You can create menu shortcuts to the STBY mode menu for menu items which you often use. Up to 20 shortcuts can be created.


### 4.7.1 How to create a menu shortcut

The procedure below shows you how to create a menu shortcut for the arrival alarm.

1. Open the STBY mode menu.
2. Select the menu item for which you want to create a menu shortcut. For example, select [ARRIVAL ALARM] from the [ALARM] menu.
3. Long press the **MENU** key to show the following prompt.



4. Press the **Course control** knob to create the shortcut. The shortcut is then added to the STBY mode menu.



### 4.7.2 How to delete a menu shortcut

1. Open the STBY mode menu.
2. Select the menu item to delete.
3. Long press the **MENU** key to show the following prompt.

--- MENU DELETE ---  
ARE YOU SURE?  
  
YES-PUSH ENTER KNOB  
NO-PUSH MENU KEY

4. Press the **Course control** knob to delete the shortcut.

#### 4. HOW TO CUSTOMIZE YOUR NAVPILOT

This page is intentionally left blank.

# 5. MAINTENANCE, TROUBLESHOOTING

This chapter provides the maintenance and troubleshooting procedures.

## WARNING

**ELECTRICAL SHOCK HAZARD**  
Do not open the equipment.

This equipment uses high voltage that can cause electrical shock. Only qualified persons can work inside the equipment.

## NOTICE

**Do not apply paint, anti-corrosive sealant or contact spray to plastic parts or equipment coating.**

Those items contain products that can damage plastic parts and equipment coating.


## 5.1 Preventive Maintenance

Regular maintenance is necessary for best performance. Create a maintenance schedule which includes the items shown below.

Item	Check point	Remedy
Control unit connectors	Check for tight connection.	Tighten loosened connectors.
LCD	Dust on the LCD dims picture.	Clean the LCD carefully to prevent damage, with tissue paper and an LCD cleaner. To remove dirt or salt deposits, use an LCD cleaner and wipe slowly with lens paper so as to dissolve the dirt or salt. Change the paper frequently so the salt or dirt will not damage the LCD. Do not use solvents like thinner, acetone or benzine for cleaning.
Ground terminal	Check for tight connection and corrosion	Clean or replace the ground wire as necessary.

## 5.2 Replacement of Fuse

Two fuses (125V 4A) in the processor unit protect the equipment from reverse polarity of the ship's mains and equipment fault. If a fuse blows, you cannot turn on the power. Have a qualified technician check the set.




Parts name	Type	Code no.	Remarks
Fuse	FGMB 125V 4A PBF	000-157-482-10	Supplied as spare parts

## 5.3 Diagnostics

Your NAVpilot contains the diagnostics that check the processor unit, control unit, NMEA 0183 input/output, CAN bus, keyboard, screen, rudder, and compass. The tests are for use by service technicians, but you can do the test to help the serviceman in troubleshooting.

### 5.3.1 Diagnostic menu

1. Press the **MENU** key to open the menu.
2. Rotate the **Course control** knob to select [OTHER MENU] then push the knob.
3. Rotate the **Course control** knob to select [SYSTEM SETUP] then push the knob.
4. Rotate the **Course control** knob to select the current setting for [DIAGNOSTIC] then push the knob.



5. Rotate the **Course control** knob to select the item to test then push the knob to start the test.
6. Press the **MENU** key continuously to quit the test and close the menu.

### 5.3.2 Processor unit test

This test checks the processor unit for correct operation. Open the diagnostic test options window, select [PROCESSOR UNIT] then push the **Course control** knob. The results for the ROM, RAM and RUDDER ANGLE are shown as OK or NG. If NG appears, repeat the test. If the error condition continues, contact your dealer.

```

PROCESSOR UNIT ID: 39768
ROM: OK 6454007-** **
RAM: OK BACKUP: OK
RUDDER ANGLE: OK 0°
BYPASS/CLUTCH: 0.7A
RC1/RC2: OFF -1° /OFF -2
INPUT VOLTAGE: 24.5 V
PORT1/PORT2/CAN - -/ -/OK
CAN ID: 39713
CPU/PWR: */*

```

\*: Program no.

\*\* \*\*: Program version no.

[ROM]: "OK" for normal, program number

[RAM]: "OK" for normal, program number

[BACKUP]: Backup data test, "OK" for normal.

[RUDDER ANGLE]: "OK" for normal, actual rudder angle.

[BYPASS/CLUTCH]: Bypass/clutch amperage. ("NOT PRESENT" shown in case of no connection.)

[RC1/RC2]: Remote controller state (ON or OFF) and rudder signal input value. "NOT USED" shown in case of no connection.

[INPUT VOLTAGE]: Voltage.

[PORT1/PORT2/CAN]: I/O test for PORT1/PORT2/CAN (CAN bus). OK for normal.

[CAN ID]: ID of CAN bus equipment

### 5.3.3 Control unit test

This test checks the control unit for correct operation. Open the diagnostic test options window, select [CONTROL UNIT] then push the **Course control** knob. The results for [ROM], [RAM], [BACKUP], and [COMMUNICATION] are shown as OK or NG (No Good). If NG appears, repeat the test. If the error condition continues, contact your dealer.

```

CONTROL UNIT
ROM: OK 6454011-**. **
RAM: OK BACKUP: OK
COMMUNICATION: OK
CONTROLLER ID: 2
CAN ID: 0


```

\*\* \*\*: Program version no.

### 5.3.4 NMEA0183 test


This test checks for correct input and output of NMEA 0183 data from PORT1 and PORT2 and requires a special test connector. (If the test is done without the connector, the results are shown as "-").

Open the diagnostic test options window, select [NMEA0183 TEST] then push the **Course control** knob. The results are shown as OK or "-". For any "-", repeat the test. If the error condition continues, contact your dealer




### 5.3.5 CAN bus test

This test checks the CAN bus network. Open the diagnostic test options window, select [CAN BUS TEST] then push the **Course control** knob. The results are shown as OK or NG (No Good). ("-") appears when there is on CAN bus connection.) If NG appears, repeat the test. If the error condition continues, contact your dealer.




### 5.3.6 Keyboard test

The keyboard test checks the key panel on the control unit. Open the diagnostic test options window, select [KEYBOARD TEST] then push the **Course control** knob. Press each key and the **Course control** knob. The related on-screen location fills in black if the key or knob is normal. Rotate the **Course control** knob. The figure inside the circle on the screen counts up or down with knob rotation.



### 5.3.7 Screen test


The screen test checks the control unit for correct presentation of black and white tones. Open the diagnostic test options window, select [SCREEN TEST] then push the **Course control** knob. Push the **Course control** knob to change the screen. Press the **MENU** key continuously to quit the test and close the menu.



### 5.3.8 Rudder test

The rudder test checks drive type, presence or absence of bypass/clutch circuit, rudder deadband, rudder speed, rudder duty\*, and rudder angle. Open the diagnostic test options window, select [RUDDER TEST] then push the **Course control** knob. You are asked to center the rudder. Center the rudder then push the **Course control** knob to start the test.

\* The rudder control value required to obtain rudder speed of 5°/sec. For solenoid systems, the indication is 100% always.




When the test is completed a message announces the results of the test.

Message	Meaning
Rudder test completed.	Rudder tested OK.
Rudder speed is too fast to control the vessel. The vessel may not be controlled properly.	Rudder speed is too fast.
Rudder speed is too slow to control the vessel. The vessel may not be controlled properly.	Rudder speed is too slow.
Deadband is too big to control the vessel. The vessel may not be controlled properly.	Deadband is too large.
Deadband is too big rudder speed is too fast to control the vessel. The vessel may not be controlled properly.	Deadband is too large; rudder speed is too fast.
Deadband is too big rudder speed is too slow to control the vessel. The vessel may not be controlled properly.	Deadband is too large; rudder speed is too slow.
Rudder test failed.	


### 5.3.9 Compass (heading sensor) test

The compass test checks the heading sensor.


1. Open the diagnostic test options window, select [COMPASS TEST] then push the **Course control** knob.



2. Push the **Course control** knob to open the compass selection window.



3. Rotate the **Course control** knob to select the sensor to test then push the **Course control** knob.



The [ROM], [RAM], [BACKUP], [SENSOR] and [RATE SENSOR] are checked and the results shown as [OK] or [NG]. If there is no sensor or rate sensor, “- -” is shown at [RATE SENSOR].

## 5.4 System Data

The system data display allows you to confirm the equipment and drive system status. To show this display, open the [SYSTEM MENU], select [SYSTEM DATA] then push the **Course control** knob.

INPUT VOLTAGE: 24.4 V CONTROLLER ID: 2 DRIVE TYPE: REVERSIBLE 24V BYPASS/CLUTCH: NOT PRESENT P/C TEMP: 71.3°F/91.1°F MOTOR DRIVE CUR.: 10.0 A BYPASS/CLUTCH CUR.: 0.0 A
---

**[INPUT VOLTAGE]:** Voltage input to the NAVpilot.

**[CONTROLLER ID]:** ID of the controller that displays the system data.

**[DRIVE TYPE]:** Drive type used with the NAVpilot.

**[BYPASS/CLUTCH]:** Presence or absence of bypass/clutch.

**[P/C TEMP]:** Temperature of processor unit / control unit.

**[MOTOR DRIVE CUR.]:** Motor drive current. Max. value is 25.0A.

**[BYPASS/CLUTCH CUR.]:** Bypass/clutch current. Max. value is 3.0A.

## 5.5 Messages

Your equipment displays messages to alert you to potential equipment problem and operation status.


### 5.5.1 Message pop-up display

When the system detects alarm violation, error, etc., the buzzer sounds and an error message pop-up display appears. The illustration below shows the message for rudder drive error. For any error message, turn off the NAVpilot and have a qualified technician check the drive circuit.

RUDDER DRIVE ERROR  
 PLEASE TURN OFF AND  
 CHECK DRIVE CIRCUIT

### 5.5.2 Message board

The message board contains the information about the latest alarm/error messages. To show the message board, press the **MENU** key to open the menu. [MESSAGE] is selected; push the **Course control** knob.



### 5.5.3 Message description

Error no.	Error message	Meaning, remedy
<b>Alarm</b>		
5101	"DEVIATION ALARM"	Deviation alarm violated.
5103	"WIND SHIFT ALARM"	Wind shift alarm violated.
5105	"ARRIVAL ALARM"	You are nearing a waypoint.
5107	"CROSS TRACK ERROR"	Your boat is off course by the amount set on the XTE alarm.
5203	"THE PRESET TIME HAS PASSED"	The watch alarm has activated. Operate any key to confirm presence.
5301	"HEADING CHANGE ALARM"	Heading change alarm violated.
5303	"TRUE WIND SPEED ALARM"	True wind alarm violated (sailboats only).
5305	"APP WIND SPEED ALARM"	Apparent wind alarm violated (sailboats only).
5307	"SPEED ALARM"	Speed alarm violated.

5. MAINTENANCE, TROUBLESHOOTING

<b>Error no.</b>	<b>Error message</b>	<b>Meaning, remedy</b>
5309	"WATER TEMP ALARM"	Water temperature alarm violated.
5311	"DEPTH ALARM"	Depth alarm violated.
5313	"TRIP ALARM"	Your boat has travelled the distance set for the trip alarm.
<b>Error</b>		
1101	"TOO FAST TO GO FISHING MODE. PLEASE SLOW DOWN LESS THAN 10 kn PUSH MENU KEY TO CANCEL AND GO TO AUTO MODE"	Set speed below 10 knots then go to respective mode.
1201	"COMMUNICATION ERROR"	No communication between processor unit and control unit. Turn off power.
1203	"FU REMOTE CONTROLLER ERROR"	Check remote controller.
1301	"MISSING HEADING DATA"	Check heading sensor.
1303	"HEADING DATA IS SHIFTED"	
1305	"NO SPEED DATA"	Check speed sensor.
1307	"NO WIND DATA"	Check wind sensor
1309	"WIND DATA IS SHIFTED"	
1311	"NO NAV DATA. WAIT FOR 1 SECONDS."	Check nav data sensor.
1315	"DEGRADATION OF NAV DATA QUALITY"	Check nav data sensor.
1317	"NO POSITION DATA"	Check position-fixing equipment.
1801	"NO CONTACT WITH EVC"	
1901	"RATE SENSOR ERROR"	Check rate sensor.
1903	"BACKUP ERROR"	All user and engineer default settings are restored. Reenter installation settings.
<b>Fail</b>		
0001	"DRIVE UNIT ERROR"	Turn off power
0003	"DRIVE UNIT OVERLOAD"	Turn off power.
0005	"DRIVE UNIT IS OVER-HEATED"	Temperature of drive circuit is higher than 80°C(176°F). Turn off power.
0007	"B/C DRIVE ERROR"	Bypass clutch error. Turn off power.
0009	"B/C IS OVERLOADED"	Bypass clutch overload. Turn off power.
0011	"B/C IS SHORTED OUT"	Bypass clutch is shorted. Turn off power.
0013	"RUDDER DRIVE ERROR"	Turn off power.
0015	"DISCONNECT B/C"	Bypass clutch is disconnected. Turn off power.
0017	"RUDDER ANGLE ERROR"	Turn off power.
0301	"COMMUNICATION ERROR"	No communication between processor unit and all control units. Turn off power.
<b>Notice</b>		
2001	"INPUT VOLTAGE IS UNDER LIMIT"	Input voltage under limit. Check power supply.
2003	"INPUT VOLTAGE IS OVER LIMIT"	Input voltage over limit. Check power supply.

<b>Error no.</b>	<b>Error message</b>	<b>Meaning, remedy</b>
2101	"PARAMETER ERROR OF NAV MODE"	Invalid parameter entered in NAV mode. Reenter parameter.
2105	"START TO TURN BY FISHING MODE"	Boat is starting to turn after dodge operation.
2107	"CIRCLE MODE STOPPED"	Circle mode was stopped.
2109	"MODE WAS CHANGED"	
2201	"WARNING. REMOTE CONTROLLER'S SW IS ON"	Remote controller switch is ON. Turn it OFF to continue operation.
2203	"THE PRESET TIME SET HAS PASSED"	Watch alarm has activated.
2301	"HEADING SOURCE ARE CHANGED"	Heading source changed.
2303	"WIND SOURCE ARE CHANGED"	Wind source changed.
2305	"POSITION SOURCE ARE CHANGED"	Position source changed.
2307	"SPEED SOURCE HAS CHANGED"	Source of speed changed.
2330	"ARRIVED AT LAST WAYPOINT"	Arrival alarm alerts you to arrival at final waypoint.
2340	"WAYPOINT WAS CHANGED"	Switching to next waypoint.
2360	"NO WATER TEMP DATA"	Check water temperature sensor.
2362	"NO DEPTH DATA"	Check depth sensor.
2901	"NO COMPASS ADJUSTMENT DATA"	Check heading sensor.

5. MAINTENANCE, TROUBLESHOOTING

This page is intentionally left blank.


# APPENDIX 1 MENU TREE

## STBY mode menu

[MENU] key

- MESSAGE (Shows error messages.)
- CONTRAST/BRILLIANCE (1-16, **8**; 1-8, **8**) (NAVPilot-711/720)
- SEA STATE
- MANUAL PARAMETER — See AUTO/NAV menu on page AP-3.
- ADVANCED AUTO
- OTHER


**Bold Italic: Default**



(Continued on next page)

APPENDIX 1 MENU TREE

(Continued from previous page)



\*1 Cannot be set higher than [RATE OF TURN] set with [SHIP'S CHARACTERISTICS] (at installation).

\*2 [SHIP'S CHARACTERISTICS]=other than sailboat

\*3 Settable when [TERMINATION] is set for [DISTANCE].

\*4 Settable when [TERMINATION] is set for [NUMBER OF TURNS].

\*5 [SHIP'S CHARACTERISTICS]=sailboat

**PATTERN and DEFAULT DISPLAY:**  
 PATTERN 1: DISPLAY 1, SOG, DISPLAY 2, POS  
 PATTERN 2: DISPLAY 2, SOG, DISPLAY 2, COG  
 PATTERN 3: DISPLAY 2, SOG, DISPLAY 2, XTE

AUTO, NAV menu

[MENU] key

- MESSAGE (Shows error messages.)
- SEA STATE (**FULL-AUTO**, SEMI-AUTO, MANUAL-CALM, MANUAL-MODERATE, MANUAL-ROUGH)
- MANUAL PARAMETER
  - WEATHER (CALM, 0°-10°, **1**; MODERATE, 0°-10°, **2**; ROUGH, 0°-10°, **3**)
  - RUDDER GAIN (CALM, 1-20, **3**; MODERATE, 1-20, **5**; ROUGH, 1-20, **10**)
  - COUNTER RUDDER (CALM, 0-20, **10**; MODERATE, 0-20, **2**; ROUGH, 0-20, **4**)
- ADVANCED AUTO (OFF, **ON**)
- OTHER MENU

This page is intentionally left blank.

**SPECIFICATIONS OF AUTOPILOT  
NAVpilot-700/711/720**

**1 CONTROL UNIT**

- 1.1 Display                                      Monochrome dot matrix LCD
- 1.2 Effective display area                NAVpilot-700: 85.2 (W) x 85.2 (H) mm (160 x 160 dot)  
NAVpilot-711/720: 85.2 (W) x 43.6 (H) mm (160 x 80 dots)
- 1.3 Backlight                                    8 steps
- 1.4 Contrast                                    16 steps
- 1.5 Useable set                                6 sets

**2 PROCESSOR UNIT**

- 2.1 Rudder mode                            STBY, Auto, Dodge, Remote, Advanced auto\*, Navigation\*, Wind\*, FishHunter\*
- 2.2 Weather mode                            FULL-AUTO/SEMI-AUTO/MANUAL-CALM/MANUAL-MODERATE/MANUAL-ROUGH
- 2.3 Weather                                    AUTO/0-10 (Manual)
- 2.4 Rudder gain                              AUTO/1-20 (Manual)
- 2.5 Counter rudder                         AUTO/0-20 (Manual)
- 2.6 Trim gain                                 AUTO/1-20 (Manual)
- 2.7 Course change speed                 1-10 deg/s
- 2.8 Rudder angle settings                10-45 deg
- 2.9 Alarm                                     Heading deviation, Arrival, Cross-track error, Ship's speed\*, Depth\*, Water temperature\*, Trip distance\*, Watch, Wind (heading change, wind shift, true, apparent)  
\*: external data required
- 2.10 Motor/ Solenoid drive                25A continuous, 50A for 5 seconds
- 2.11 Clutch/ Bypass drive                3A

**3 INTERFACE**

- 3.1 Number of ports                        Nav. data: 2, CAN bus: 1, Relay contact: 2, Contact input: 2, USB: 1 (PC for maintenance only)
- 3.2 Data sentences                         NMEA 0183 Ver1.5/2.0/3.0  
Input                                        AAM, APB, BOD, BWC, BWR, DBT, DPT, GGA, GLL, GNS, HDG, HDM, HDT, MTW, MWV, ROT, RMB, RMC, THS, TLL, VHW, VTG, VWR, VWT, XTE, ZDA  
Output                                      DBT, DPT, GGA, GLL, GNS, HDG, HDM, HDT, MTW, MWV, RMB, RMC, ROT, RSA, VHW, VTG, VWR, VWT, ZDA

**3.3 CAN bus PGN (NMEA2000)**

Input 059392, 059904, 060928, 061184, 126208, 126464, 126720,  
126992, 126996, 127250, 127251, 127258, 127488, 127489,  
128259, 128267, 129025, 129026, 129029, 129033, 129283,  
129284, 129285, 130306, 130310, 130311, 130312, 130313,  
130314, 130577, 130880

3.4 Output 059392, 059904, 060928, 061184, 126208, 126464, 126270,  
126992, 126996, 127245, 127250, 127251, 127258, 127259,  
128267, 129025, 129026, 129029, 129033, 129283, 129284,  
129285, 130306, 130310, 130311, 130312, 130822, 130823

3.4 Universal output port 3 A max: 2 (relay contact)

**4 POWER SUPPLY**

12-24 VDC: 4-2 A (control unit: 6 sets)

**5 ENVIRONMENTAL CONDITION** Ambient temperature -15°C to +55°C

5.2 Relative humidity 95% at 40°C

**5.3 Degree of protection**

Control unit IP56

Processor unit IP20

Rudder reference unit IPX5

5.4 Vibration IEC 60945

**6 UNIT COLOR** Control/processor unit N2.5

6.2 Remote controller N3.0 (FAP-5552/6232), N1.5 (FAP-6212/6222)

6.3 Rudder reference unit N1.5

6.4 Junction box N3.0

# INDEX

---

## **Numerics**

- 180-degree turn..... 2-11
- 360-degree turn..... 2-11

## **A**

- ADVANCED AUTO mode ..... 2-4
- Alarm buzzer ..... 3-2
- Alarm log ..... 4-10
- Alarm menu..... 3-1
- Alarms
  - alarm menu ..... 3-1
  - apparent wind speed alarm ..... 3-9
  - arrival alarm ..... 3-5
  - buzzer ..... 3-2
  - buzzer interval ..... 3-2
  - depth alarm ..... 3-6
  - deviation ..... 3-3
  - heading change alarm..... 3-8
  - speed alarm ..... 3-5
  - trip distance alarm..... 3-7
  - true wind speed alarm ..... 3-9
  - watch alarm ..... 3-3
  - water temperature alarm ..... 3-6
  - wind shift alarm ..... 3-9
  - XTE alarm ..... 3-4
- Apparent wind speed alarm ..... 3-9
- Arrival alarm ..... 3-5
- Arrow key function..... 4-9
- AUTO mode ..... 2-2

## **B**

- Brilliance adjustment ..... 1-4
- Button-type remote controller (FAP-6221, FAP-6222) ..... 2-18
- Buzzer interval ..... 3-2
- Buzzer volume ..... 4-9

## **C**

- CAN bus test ..... 5-4
- Circle turn..... 2-14
- Compass (heading sensor) test ..... 5-7
- Compass, rudder display ..... 1-8
- Contrast adjustment ..... 1-4
- Control description
  - NAVpilot-700 ..... 1-1
  - NAVpilot-711 ..... 1-2
  - NAVpilot-720 ..... 1-2
- Control unit test ..... 5-3
- Counter rudder setting ..... 4-4
- Course after remote operation ..... 4-7

## **D**

- Depth alarm..... 3-6
- Depth display ..... 1-8
- Deviation alarm ..... 3-3

## Diagnostics

- compass (heading sensor) test ..... 5-7
- control unit test ..... 5-3
- diagnostics menu ..... 5-2
- keyboard test..... 5-5
- NMEA 0183 test ..... 5-4
- processor unit test..... 5-3
- rudder test ..... 5-6
- screen test..... 5-5
- Dial-type remote controller (FAP-5551, FAP-5552) ..... 2-17
- Display data in AUTO mode..... 4-10, 4-11
- Display mode
  - NAVpilot-700 ..... 1-5
  - NAVpilot-711/720 ..... 1-6
- Display settings saving, loading ..... 4-10
- DODGE mode
  - AUTO mode ..... 2-21
  - NAV mode ..... 2-21
  - STBY mode ..... 2-21
- Dodge-type remote controller (FAP-6231, FAP-6232) ..... 2-19

## **E**

- Engine speed display ..... 1-9

## **F**

- Figure-eight turn..... 2-16
- FishHunter mode
  - circle turn..... 2-14
  - figure-eight turn ..... 2-16
  - orbit turn ..... 2-15
  - spiral turn ..... 2-15
  - square turn ..... 2-16
  - zigzag turn..... 2-16
- Fuse replacement ..... 5-2

## **H**

- Heading change alarm ..... 3-8
- Highway display ..... 1-9

## **K**

- Key beep ..... 4-9
- Key lock..... 4-9
- Keyboard test ..... 5-5

## **M**

- Maintenance..... 5-1
- Menu shortcuts
  - creating ..... 4-12
  - deleting..... 4-13
- Menu tree ..... AP-1
- Messages ..... 5-9

## INDEX

### **N**

- NAV mode
  - boat's behavior after switching waypoint...2-9
  - data source .....4-7
  - description.....2-6
  - sailing method for.....2-8
  - waypoint switching method .....2-9
- NAV net vx2 synchronization .....4-8
- Net towing .....4-6
- NMEA 0183 test .....5-4

### **O**

- Orbit turn .....2-15

### **P**

- Panel dimmer .....4-9
- Parameter setup menu .....4-1
- Password .....4-9
- POWER/BRILL key (NAVpilot-700) .....1-3
- Processor unit test .....5-3

### **R**

- REMOTE mode.....2-17
- Rudder display .....1-10
- Rudder gain setting .....4-4
- Rudder test .....5-6

### **S**

- Screen test.....5-5
- Sea state
  - automatic setup.....4-2
  - manual setup.....4-3
- Simulation mode .....4-10
- Speed alarm.....3-5
- Speed calculation.....4-6
- Spiral turn.....2-15
- Square turn .....2-16
- STBY key (NAVpilot-711/720) .....1-3
- STBY mode
  - description.....2-1
  - selection of data .....1-11
- STBY/POWER key (NAVpilot-720) .....1-3
- Synchronization of control units .....4-10
- System configuration ..... vii
- System data .....5-8

### **T**

- TACK mode
  - AUTO mode .....2-24
  - damping interval for wind data .....2-28
  - fast, slow tracking rate of turn .....2-25
  - fixed tack angle .....2-25
  - max rudder angle .....2-27
  - tack timer.....2-28
  - WIND mode.....2-25
- Trim gain setting .....4-5
- Trip distance alarm .....3-7
- Trip distance reset .....3-7
- True wind speed alarm .....3-9
- Turn angle in TURN mode .....4-9

### **TURN mode**

- 180-degree turn.....2-11
- 360-degree turn.....2-11
- turn selection.....2-10
- user turn .....2-11

### **U**

- User settings saving, loading .....4-10
- User turn .....2-11

### **W**

- Watch alarm .....3-3
- Water temperature alarm .....3-6
- Water temperature display .....1-10
- Weather setting.....4-3
- Wind display .....1-10
- WIND mode
  - starting .....2-22
  - wind angle .....2-23
- Wind shift alarm .....3-9

### **X**

- XTE alarm .....3-4

### **Z**

- Zigzag turn .....2-16